

Crack Monitor Installation

ANCHORS & BOLTS/SCREWS

1. Place Monitor over crack and mark position for anchors.
2. Drill holes for anchors.
3. Attach monitor with bolts or screws, ensuring that red crosshairs center on grid.
4. Cut tape and remove from monitor.
5. Note location of monitor on crack data sheet.

EPOXY ADHESIVE

1. Clean surface to remove debris.
2. Use quick setting epoxy
3. Apply epoxy to back of both monitor plates, following directions on epoxy package.
4. Press monitor in place across crack.
5. Make sure red crosshairs are centered on grid. Adjust if necessary.
6. Use duct tape to hold gauge in place till epoxy cures.
7. After epoxy cures, cut clear tape and remove from front of monitor.
8. Note location of monitor on crack data sheet.

